C-10

Flash Brackets/Umbrella Holders/Flexgrip Holders

\$samigon® One-Touch Folding Bracket

All metal, folding 90° shoe bracket. Molded hand grip and rubberized bed over hard metal makes this bracket a sturdy, convenient device for use on 35mm cameras. Extremely portable as it folds neatly and can fit into clothes pocket. Opens up for use and snaps into position. Spring lock holds upright shoe arm tightly. To close, release spring. Cable release socket accepts most releases. Samigon blister pack. Master: 10.



CSA413 C

One Touch Folding Bracket

\$samigon® Straight Flash Bracket

Strong aluminum alloy bar (8" long x 1" wide). Rubber base is 6" long to prevent camera slippage. Locking camera travels along 5 3 /8" cut for centering camera. 1 /4 x 20 screw. Built-in flash shoe for mounting flashgun. Tripod socket permits mounting on tripod. Samigon blister pack. Master: 10.



CSA415 Straight Flash Bracket

\$samigon® Right Angle Bracket

Rigid metal bracket to fit all cameras. Grip at 90°. Covered mounting surface affords good protection to camera. Excellent quality. With hand strap. Made in Germany. Samigon blister pack. Master: 5.

CSA822

Right Angle Bracket

SamigonPro Umbrella Holder

Mounts any umbrella on light stand. Accepts all shoe mounting flashguns.
Tilts 180°; swivels 360°.
Fits all light stands up to 5/8".
Black finish. 5" high; swivels in center. Blister packed.



CPM/Delta Flip-Flash Brackets

Ensures natural even lighting. By permitting you to keep the flash over the lens in a horizontal or vertical position it eliminates disturbing shadows and "red-eye".

The easy to hold bracket has fatigue-free, foam grip. It allows you to flip, maneuver, and hold flash units in any direction, and includes bounce flash capability.

Accepts all shoe-type or tripod flash attachments. A 2" wide bracket fits 35mm or medium format cameras. All hardware is included.

The Flip Flash I is 7" long. The Flip Flash II is 18" long and reinforced to stay where you put it.

BCP242260 Flip Flash Bracket I CCP46194 Flip Flash Bracket II

46190 46194

CPM/Delta Universal Umbrella Bracket

For placement of umbrella/flash heads or lights. Machined from solid aircraft aluminum with a 90° tilt and 360° rotation. Fits male/female 1/4" - 20 tripod threads, male/female 3/8" and 5/8" light stands. 20 different combinations are possible. Adapters included.

A flash adapter accepts all shoe-type flash attachments.



BCP242200 Universal Umbrella Bracket

46140

CPM/Delta Flexgrip Holders

Feature double-ended, flexible stainless steel spring clips and/or rubber-coated "A" clamps. Hold diffusers, gels, gobos, and reflector cards in place. They bend, twist, and stay exactly where you want them.



CCP46114	Flexgrip 1" Clamp/Clip, 6" long	46114
CCP46116	Flexgrip 1" Clamp/Clip, 12" long	46116
CCP46118	Flexgrip 1" Dual Clamp, 8" long	46118
CCP46119	Flexgrip 1/2" Dual Clamp, 6" long	46119

CSA438 Pro Umbrella Holder

FOR FAST DELIVERY CALL TOLL FREE!

EAST 1-888-ARGRAPH OR 1-800-526-6290 WEST 1-888-WESTARG OR 1-800-323-9069